


4/2 Solenoid Valve




4 Ports A,B,P,R 2 Valve Positions



Normally used on a Double Acting Cylinder

5/2 Solenoid Valve



5 Ports (A,B,P,EA, EB)

2 Valve Positions

Used for Double Acting Valves

